


M-Edge e-Luminator 2 for Amazon Kindle Instructions



Battery Installation Instructions:

1. Unscrew battery cap (A)
2. Insert a single AAA battery (not included, alkaline recommended) into the battery compartment (B) with the positive end of the battery first
3. Replace battery cap (A)

Battery Removal Instructions:

1. Unscrew battery cap (A)
2. Tap location E on support system gently against palm of hand. Battery should slide out partially
3. Remove battery

Installation Instructions:

1. Slide Rotating support system (C) into e-Luminator pocket of compatible M-Edge jackets, cases and covers

e-Luminator Use Instructions:

1. Slide power switch (D) to turn on/off light:
 - center position (off)
 - bottom position (low intensity)
 - top position (high intensity)
2. Rotate support arm about battery housing (B) for:
 - down position - storage in spine of jacket
 - up position - use for downlight on Kindle screen
3. Position flexible neck for desired lighting direction